



# GSM

## Quectel Cellular Engine

**GSM MMS  
AT Commands**

GSM\_MMS\_ATC\_V1.2











## 2. AT Commands for MMS

Quectel GSM/GPRS module supports to transfer MMS Message over HTTP protocol. The MMS service supports the following character sets: US-ASCII, UTF8, UCS2 (Big Endian), and GBK. It is recommended to use PDU (HEX) mode to input MMS Message title if the character set is not US-ASCII.

### 2.1. Overview

Command	Description
AT+QMMURL	Set the URL of the MMSC
AT+QMMPROXY	Set the MMS proxy
AT+QMMCFG	Set the parameter for sending MMS Message
AT+QMMSCS	Set character sets and input mode
AT+QMMSW	Write MMS Message
AT+QMMSEND	Send MMS Message
AT+QMMRM	Manage the received MMS Message
AT+QMMRR	Read received MMS Message
AT+QMMRECV	Receive MMS Message from the MMSC
AT+QMMPRI	Set priority of MMS Message and call
AT+QMMDUR	Set DURATION attribute value in the SMIL script
AT+QMMSMS	Set MMS's SMS transactor
AT+QMMCENP	Enable to output text in UTF8
AT+QMMFTYP	Output file style

Note: M95 and M72 module do not support to receive MMS message.

TA will switch to data mode after executing **AT+QMMRR** command. To switch back to AT mode, please input “++” and this will terminate the current MMS AT command. The interval time between the first “+” and the character before the first “+” **MUST NOT** be less than 500 ms and the interval time between the last “+” and the character next to the last “+” **MUST NOT** be less than 500 ms and the interval time between each “+” **MUST** be less than 1000 ms.

### 2.2. Detailed descriptions of commands

#### 2.2.1. AT+QMMURL Set the URL of the MMSC

AT+QMMURL Set the URL of the MMSC	
Test Command	Response
AT+QMMURL=?	+QMMURL: “URL”

	<p><b>OK</b></p> <p>Parameter See Write Command.</p>
Read Command <b>AT+QMMURL?</b>	<p>Response <b>+QMMURL: &lt;mmsc url&gt;</b></p> <p><b>OK</b></p> <p>Parameter See Write Command.</p>
Write Command <b>AT+QMMURL=&lt;mmsc url&gt;</b>	<p>Response <b>OK</b></p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameter <b>&lt;mmsc url&gt;</b> The URL of the MMSC</p>
Reference	<p>Note: The maximum length of URL is 100 bytes.</p>

### 2.2.2. AT+QMMPROXY Set the MMS proxy

<b>AT+QMMPROXY Set the MMS proxy</b>	
Test Command <b>AT+QMMPROXY=?</b>	<p>Response <b>+QMMPROXY: (1),“(0-255).(0-255).(0-255).(0-255)”,(0-65535)</b></p> <p><b>OK</b></p> <p>Parameter See Write Command.</p>
Read Command <b>AT+QMMPROXY?</b>	<p>Response <b>+QMMPROXY: &lt;type&gt;,&lt;gateway&gt;,&lt;port&gt;</b></p> <p><b>OK</b></p> <p>Parameter See Write Command.</p>
Write Command <b>AT+QMMPROXY=&lt;type&gt;,&lt;gateway&gt;[,&lt;port&gt;]</b>	<p>Response <b>OK</b></p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p> <p>Parameter  <b>&lt;type&gt;</b>     <u>1</u>    HTTP protocol  <b>&lt;gateway&gt;</b>   IP address of MMS proxy  <b>&lt;port&gt;</b>       Port of MMS proxy. The range of the parameter is</p>

	0-65535. Default is 80
Reference	

### 2.2.3. AT+QMMCFG Set the parameters for sending MMS Message

AT+QMMCFG Set the parameters for sending MMS Message	
Test Command AT+QMMCFG=?	<p>Response</p> <p>+QMMCFG: (0-6), (0-3),(0,1),(0,1),(0-2),(0-4)</p> <p><b>OK</b></p> <p>Parameter</p> <p>See Write Command.</p>
Read Command AT+QMMCFG?	<p>Response</p> <p>+QMMCFG: &lt;valid&gt;,&lt;pri&gt;,&lt;sendrep&gt;,&lt;readrep&gt;,&lt;visible&gt;,&lt;class&gt;</p> <p><b>OK</b></p> <p>Parameter</p> <p>See Write Command.</p>
Write Command AT+QMMCFG=<valid>[,<pri>][,<sendrep>][,<readrep>][,<visible>][,<class>]	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality: +CME ERROR: &lt;err&gt;</p> <p>Parameter</p> <p>&lt;valid&gt;      The validity period of MMS Message</p> <p>0    1 hour</p> <p>1    12 hours</p> <p>2    24 hours</p> <p>3    2 days</p> <p>4    1 week</p> <p>5    Maximum</p> <p>6    Use the network configuration</p> <p>&lt;pri&gt;      Priority</p> <p>0    Low</p> <p>1    Normal</p> <p>2    High</p> <p>3    Use the network configuration</p> <p>&lt;sendrep&gt;    0    Do not need delivery report</p> <p>1    Need delivery report</p> <p>&lt;readrep&gt;    Whether or not to read report</p> <p>0    No</p> <p>1    Yes</p> <p>&lt;visible&gt;    Indicate whether or not to hide address</p>



	<p>0 Hide any address</p> <p>1 Show even secret address</p> <p><u>2</u> Use the network configuration</p> <p><b>&lt;class&gt;</b> The class of the MMS Message</p> <p><u>0</u> Personal</p> <p>1 Advertisement</p> <p>2 Informational</p> <p>3 Auto</p> <p>4 Use the network configuration</p>
Reference	

#### 2.2.4. AT+QMMSCS Set character sets and input mode

AT+QMMSCS Set character sets and input mode	
Test command <b>AT+QMMSCS=?</b>	Response <b>+QMMSCS: ("ASCII","UTF8","UCS2","GBK"),(0,1)</b>  <b>OK</b> Parameter See Write Command.
Read command <b>AT +QMMSCS?</b>	Response <b>+QMMSCS: &lt;charset&gt;,&lt;input mode&gt;</b>  <b>OK</b> Parameter See Write Command.
Write command <b>AT+QMMSCS =&lt;charset&gt;[,&lt;input mode&gt;]</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b> Parameter <b>&lt;charset&gt;</b> A string parameter which indicates the type of character sets: "ASCII" US-ASCII character set <u>"UTF8"</u> UTF8 character set "UCS2" ISO-10646-UCS-2 character set; this needs to specify Big Endian order. "GBK" GBK character set <b>&lt; input mode&gt;</b> The mode to input or view MMS Message title <u>0</u> PDU(HEX) mode 1 Text (BIN) mode
Reference	Note:

	<p>This settings affect the following commands:</p> <p><b>AT+QMMSW=4,1</b>, input MMS Message title.</p> <p><b>AT+QMMSW=4</b>, view MMS Message title.</p> <p><b>AT+QMMSW=5,1,"test.txt"</b>, append a text file.</p>
--	---

### 2.2.5. AT+QMMSW Write MMS Message

<b>AT+QMMSW Write MMS Message</b>	
Test command <b>AT+QMMSW=?</b>	Response <b>+QMMSW: (0-5)</b>  <b>OK</b>
	Parameter See Write Command.
Write command 1) If MMS title is written (<function>=4 and <operate>=1): <b>AT+QMMSW=&lt;function&gt;,&lt;operate&gt;</b> > title string is entered <ctrl-Z> 2) Otherwise: <b>AT+QMMSW=&lt;function&gt;[,&lt;operate&gt;][,&lt;oprstring&gt;]</b>	Response If the operation is successful: <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameter <b>&lt;function&gt;</b> Operate function 0 Clean all the content of MMS Message 1 Operate "TO address" 2 Operate "CC address" 3 Operate "BCC address" 4 Operate title 5 Operate file appended <b>&lt;operate&gt;</b> It is omitted if <function> is 0 0 Clean 1 Write <b>&lt;oprstring&gt;</b> Address string if <function> is 1, 2 or 3, the length of which must be less than 50. File name if <function> is 5, the length of which must be less than 13
Reference	Note: <ul style="list-style-type: none"> <li>● The maximum number of "TO address" is 6.</li> <li>● The maximum number of "CC address" is 6.</li> <li>● The maximum number of "BCC address" is 6.</li> <li>● Address could be a subscriber number or an email address (e.g. info@quectel.com).</li> <li>● The file to be appended must have been stored in UFS. It is strongly recommended that the file name should use DOS 8.3</li> </ul>

	<p>format.</p> <ul style="list-style-type: none"> <li>● The maximum length of MMS Message title is 100.</li> <li>● The character set of the MMS Message title or the content of a text file are specified by <b>AT+QMMSCS</b>. For example: If the content of a text file uses UTF8 character set, <b>AT+QMMSCS="UTF8",0</b> must be executed firstly.</li> </ul>
--	---

### 2.2.6. AT+QMMSSEND Send MMS Message

AT+QMMSSEND Send MMS Message	
Test Command <b>AT+QMMSSEND=?</b>	Response <b>+QMMSSEND: (1)</b>  <b>OK</b>
	Parameter See Write Command.
Write Command <b>AT+QMMSSEND=&lt;operate&gt;</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameter <b>&lt;operate&gt;</b> 1    Start to send
Reference	Note: The response <b>OK</b> means starting to send MMS Message. When MMS Message sending has finished, an unsolicited result code will be returned: <b>" +QMMNOTIFY: 1,&lt;mms index&gt;,&lt;error code&gt;".</b> It means sending MMS Message successfully if <b>&lt;error code&gt;</b> is equal to 0.

### 2.2.7. AT+QMRRM Manage the received MMS Message

AT+QMRRM Manage the received MMS Message	
Test command <b>AT+QMRRM=?</b>	Response <b>+QMRRM: (0-1)</b>  <b>OK</b>
	Parameter See Write Command.
Write command <b>AT+QMRRM=&lt;operate&gt;</b>	Response If the <b>&lt;operate&gt;</b> =1 is to list MMS Message:

<p>ate&gt;[,&lt;from&gt;][,&lt;to&gt;]</p>	<p><b>+QMMRM:</b> &lt;mms index&gt;,&lt;from address&gt;,&lt;ind&gt;,&lt;date&gt;,&lt;time&gt;,&lt;message size&gt; [...]</p> <p><b>OK</b> Otherwise: <b>OK</b></p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p> <hr/> <p>Parameter</p> <p><b>&lt;operate&gt;</b>      0    Delete MMS Message                          1    List MMS Message</p> <p><b>&lt;from&gt;</b>            The beginning to be operated index of MMS Message. The minimum index is 1.</p> <p><b>&lt;to&gt;</b>                The end to be operated index of MMS Message. The minimum index is 1.</p> <p><b>&lt;mms index&gt;</b>      The index of MMS Message</p> <p><b>&lt;from address&gt;</b>   Origination address</p> <p><b>&lt;ind&gt;</b>                0    The MMS Message is not downloaded                          1    The MMS Message has been downloaded</p> <p><b>&lt;date&gt;</b>             Download date. Its format is MM/DD/YYYY. e.g. "07/25/2009"(GMT)</p> <p><b>&lt;time&gt;</b>             Download time. Its format is HH:MM:SS. e.g. "10:25:56"(GMT)</p> <p><b>&lt;message size&gt;</b>   MMS Message size in bytes</p>
Reference	

**2.2.8. AT+QMMRR Read a received MMS Message**

AT+QMMRR Read a received MMS Message	
<p>Test command <b>AT+QMMRR=?</b></p>	<p>Response <b>+QMMRR: (1-5)</b></p> <p><b>OK</b></p> <hr/> <p>Parameter See Write Command.</p>
<p>Write command <b>AT+QMMRR=&lt;operate&gt;[,&lt;mms index&gt;][,&lt;para&gt;][,&lt;file name&gt;]</b></p>	<p>Response</p> <p>The following is the format to view "Origination address", "TO address" and "CC address"(&lt;operate&gt;=1,2, or 3; &lt;para&gt; is omitted): <b>+QMMRR: 1,&lt;address&gt;</b></p> <p><b>OK</b></p>

	<p>The following is the format to view MMS Message title (&lt;operate&gt;=4):</p> <p><b>+QMMRR: 4,&lt;charset&gt;,&lt;title data&gt;</b></p> <p><b>OK</b></p> <p>The following is the format to list append file (&lt;operate&gt;=5; &lt;para&gt; is omitted):</p> <p><b>+QMMRR: 5,&lt;file index&gt;,&lt;file name&gt;,&lt;charset&gt;,&lt;file size&gt;</b> [...]</p> <p><b>OK</b></p> <p>The following is the format to read the content of a file (AT command <b>AT+QMMRR=6, &lt;mms index&gt;,&lt;para&gt;</b> is entered):</p> <p><b>CONNECT</b></p> <p>TA switches to data mode, and the bin data of the file will be outputted. After the file is read over, TA will return to command mode and reply the following codes:</p> <p><b>+QMMRR: 6,&lt;download size&gt;,&lt;checksum&gt;</b></p> <p><b>OK</b></p> <p>The following is the format to copy the content of file to UFS (AT command <b>AT+QMMRR=6,&lt;mms index&gt;,&lt;para&gt;,&lt;file name&gt;</b> is entered):</p> <p><b>OK</b></p> <p>If error is related to ME functionality:</p> <p><b>+CME ERROR: &lt;err&gt;</b></p>												
	<table border="0"> <tr> <td>Parameter</td> <td></td> </tr> <tr> <td>&lt; operate &gt;</td> <td> <ul style="list-style-type: none"> <li>1 View origination address</li> <li>2 View "TO address"</li> <li>3 View "CC address"</li> <li>4 View MMS title</li> <li>5 List "Append file"</li> <li>6 Read append file data of MMS Message</li> </ul> </td> </tr> <tr> <td>&lt;mms index &gt;</td> <td>Received MMS Message index, base 1.</td> </tr> <tr> <td>&lt;para&gt;</td> <td>                     If &lt;operate&gt; is 6, it indicates file index.                      If &lt;operate&gt; is 4, it indicates output mode.                 </td> </tr> <tr> <td></td> <td> <ul style="list-style-type: none"> <li>0 PDU (HEX) mode</li> <li>1 Text (BIN) mode</li> </ul>                     If &lt;operate&gt; is not 4 or 6, &lt;para&gt; is omitted.                 </td> </tr> <tr> <td>&lt; file name &gt;</td> <td>It is valid only if &lt;operate&gt; is 6</td> </tr> </table>	Parameter		< operate >	<ul style="list-style-type: none"> <li>1 View origination address</li> <li>2 View "TO address"</li> <li>3 View "CC address"</li> <li>4 View MMS title</li> <li>5 List "Append file"</li> <li>6 Read append file data of MMS Message</li> </ul>	<mms index >	Received MMS Message index, base 1.	<para>	If <operate> is 6, it indicates file index. If <operate> is 4, it indicates output mode.		<ul style="list-style-type: none"> <li>0 PDU (HEX) mode</li> <li>1 Text (BIN) mode</li> </ul> If <operate> is not 4 or 6, <para> is omitted.	< file name >	It is valid only if <operate> is 6
Parameter													
< operate >	<ul style="list-style-type: none"> <li>1 View origination address</li> <li>2 View "TO address"</li> <li>3 View "CC address"</li> <li>4 View MMS title</li> <li>5 List "Append file"</li> <li>6 Read append file data of MMS Message</li> </ul>												
<mms index >	Received MMS Message index, base 1.												
<para>	If <operate> is 6, it indicates file index. If <operate> is 4, it indicates output mode.												
	<ul style="list-style-type: none"> <li>0 PDU (HEX) mode</li> <li>1 Text (BIN) mode</li> </ul> If <operate> is not 4 or 6, <para> is omitted.												
< file name >	It is valid only if <operate> is 6												

	<p>&lt;download size&gt; The size of the downloaded data</p> <p>&lt;checksum&gt; The checksum of the downloaded data</p>
Reference	<p>Note:</p> <p>&lt;checksum&gt; is 16 bit checksum based on bitwise XOR.</p>

### 2.2.9. AT+QMMRECV Receive a MMS Message from MMSC

AT+QMMRECV Receive a MMS Message from MMSC	
Test Command <b>AT+QMMRECV=?</b>	Response <b>+QMMRECV: (1-20),(1)</b>  <b>OK</b>
	Parameter See Write Command.
Write Command <b>AT+QMMRECV=&lt;mms index &gt;,&lt;operate&gt;</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameter <b>&lt; mms index &gt;</b> MMS Message index which starts from 1 <b>&lt;operate&gt;</b> 1 Start to receive MMS Message
Reference	Note: The response <b>OK</b> means starting to receive MMS Message. When MMS Message receiving has finished, an unsolicited result code will be returned: <b>“+QMMNOTIFY: 2,&lt;mms index&gt;,&lt;error code&gt;”</b> . It means receiving MMS Message successfully if <b>&lt;error code&gt;</b> is equal to 0.

### 2.2.10. AT+QMMPRI Set priority of MMS Message and call

AT+QMMPRI Set priority of MMS Message and call	
Test Command <b>AT+QMMPRI =?</b>	Response <b>+QMMPRI: (0,1)</b>  <b>OK</b>
	Parameter See Write Command.
Read Command <b>AT+QMMPRI?</b>	Response <b>+QMMPRI: &lt;pri&gt;</b>

	<b>OK</b> Parameter See Write Command.
Write Command <b>AT+QMMPRI=&lt;pri&gt;</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameter <b>&lt;pri&gt;</b> Priority 0 Call has higher priority than MMS Message <u>1</u> MMS Message has higher priority than call
Reference	

### 2.2.11. AT+QMMDUR Set DUR attribute value in the SMIL script

<b>AT+QMMDUR Set DUR attribute value in the SMIL script</b>	
Test Command <b>AT+QMMDUR=?</b>	Response <b>+QMMDUR: (0-4294967295)</b>  <b>OK</b>
	Parameter See Write Command.
Read Command <b>AT+QMMDUR?</b>	Response <b>+QMMDUR: &lt;durattribute&gt;</b>  <b>OK</b>
	Parameter See Write Command.
Write Command <b>AT+QMMPRI=&lt;dur attribute &gt;</b>	Response <b>OK</b> If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameter <b>&lt;durattribute&gt;</b> DUR attribute value The range is 0 to 4294967295. Default is 120000. Unit is ms.
Reference	

### 2.2.12. AT+QMMSMS Set MMS's SMS transactor

AT+QMMSMS Set MMS's SMS transactor	
Test Command AT+QMMSMS=?	Response +QMMSMS: (0,1)  <b>OK</b>
	Parameter See Write Command
Read Command AT+QMMSMS?	Response +QMMSMS: <smstosim>  <b>OK</b>
	Parameter See Write Command.
Write Command AT+QMMSMS=<smstosim>	Response <b>OK</b>  If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
	Parameter <smstosim> Set MMS's SMS transactor 0 As MMS messages handling 1 As SMS messages handling
Reference	Note: When set AT+QMMSMS=1, AT+QMMXXX commands can't be used to download and read the MMS.

### 2.2.13. AT+QMMCTYP Enable to output TEXT in UCS2

AT+QMMCTYP Enable to output TEXT in UCS2	
Test Command AT+QMMCTYP=?	Response +QMMCTYP: (0,1), (0,1)  <b>OK</b>
	Parameter See Write Command
Read Command AT+QMMCTYP?	Response +QMMCTYP: <enableucs2>,<bigendian>  <b>OK</b>
	Parameter



	See Write Command.
Write Command <b>AT+QMMCTYP=&lt;enableucs2&gt;,&lt;bigendian&gt;</b> >	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b></p> <hr/> <p>Parameter</p> <p><b>&lt;enableucs2&gt;</b> Whether to enable to output TEXT in UCS2 or not  <u>0</u> Disable  1 Enable</p> <p><b>&lt;bigendian&gt;</b> Endianness  <u>0</u> UCS2 big endian  1 UCS2 little endian</p>
Reference	<p>Note:</p> <p>If <b>&lt;enableucs2&gt;</b> is set as 1, when reading MMS, the following content will be output as UCS2 format:</p> <p>1) Title with ASCII and UTF8 encoding (<b>AT+QMMRR=4,&lt;mms index&gt;[,&lt;output mode&gt;]</b>)</p> <p>2) Text file with UTF8 encoding (<b>AT+QMMRR=5,&lt;mms index&gt;</b> &amp; <b>AT+QMMRR=6,&lt;index&gt;,&lt;fileindex&gt;</b>)</p> <p><b>Example:</b></p> <p>1) Set <b>AT+QMMCTYP=0,0</b>  <b>AT+QMMRR=4,1</b> // Read ASCII TXT MMS title  <b>+QMMRR: 4,"ASCII",6D75746920666696C6500</b></p> <p><b>OK</b>  <b>AT+QMMRR=5,1</b> // List appended file list  <b>+QMMRR: 5,1,"s.smil","UTF8",880,13</b></p> <p><b>+QMMRR: 5,2,"cont1.txt","UTF8",5,3</b></p> <p><b>+QMMRR: 5,5,"pic1.jpg","",17068,7</b></p> <p><b>OK</b>  <b>AT+QMMRR=6,1,2</b> // Read UTF8 file  <b>CONNECT</b>  <b>test1</b>  <b>+QMMRR: 6,5,3611</b></p> <p><b>OK</b></p> <p>2) Set <b>AT+QMMCTYP=1,1</b>  <b>AT+QMMRR=4,1</b> // Output MMS title using UCS2 encoding</p>

	<p><b>+QMMRR:</b>  <b>4,"UCS2","6D007500740069002000660069006C0065000000"</b></p> <p><b>OK</b></p> <p><b>AT+QMMRR=5,1</b> // List appended file list. For UTF8 file,          &lt;charset&gt; and &lt;file size&gt; are changed to UCS2 attributes.</p> <p><b>+QMMRR: 5,1,"s.smil","UCS2",1760,13</b></p> <p><b>+QMMRR: 5,2,"cont1.txt","UCS2",10,3</b></p> <p><b>+QMMRR: 5,5,"pic1.jpg","",17068,7</b></p> <p><b>OK</b></p> <p><b>AT+QMMRR=6,1,2</b> // Use UCS2 format to output TXT file content</p> <p><b>CONNECT</b></p> <p><b>test1</b></p> <p><b>+QMMRR: 6,10,2700</b></p> <p><b>OK</b></p>
--	--

#### 2.2.14. AT+QMMFTYP Output file style

AT+QMMFTYP Output file style	
Test Command <b>AT+QMMFTYP=?</b>	Response <b>+QMMFIYP: (0,1)</b>  <b>OK</b>  Parameter See Write Command
Read Command <b>AT+QMMFTYP?</b>	Response <b>+QMMFTYP: &lt;outputstyle&gt;</b>  <b>OK</b>  Parameter See Write Command.
Write Command <b>AT+QMMFTYP=&lt;ou            tputstyle&gt;</b>	Response <b>OK</b>  If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>  Parameter <b>&lt;outputstyle&gt;</b> Whether or not to output file style

	<u>0</u> Do Not output 1 Output
Reference	<p>Note:</p> <p>When set <code>AT+QMMFTYP=1</code>, run <code>AT+QMMRR=5,&lt;mmsindex&gt;</code> to list file, respond:</p> <p><b>+QMMRR: 5,&lt;fileindex&gt;,&lt;file name&gt;,&lt;charset&gt;,&lt;filesize&gt;,&lt;filetype&gt;</b></p> <p>Parameter <b>&lt;filetype&gt;</b>:</p> <ul style="list-style-type: none"> <li>0 Unknown type</li> <li>1 Text</li> <li>2 Text/html</li> <li>3 Text/plain</li> <li>4 Text/xml</li> <li>5 Image</li> <li>6 Image/gif</li> <li>7 Image/jpeg</li> <li>8 Image/tiff</li> <li>9 Image/png</li> <li>0 Image/wbmp</li> <li>11 Audio</li> <li>12 Video</li> <li>13 SMIL</li> </ul>

### 3. URC for MMS

URC	Meaning
<b>+QMMNOTIFY: 1,&lt;mms index&gt;,0</b>	Send MMS Message successfully, <mms index> is 0.
<b>+QMMNOTIFY: 1,&lt;mms index&gt;,&lt;error code&gt;</b>	Sending MMS Message failed, <mms index> is 0. Please refer to Chapter 4 for <error code>.
<b>+QMMNOTIFY: 2,&lt;mms index&gt;,0</b>	Receive MMS Message successfully.
<b>+QMMNOTIFY: 2,&lt;mms index&gt;,&lt;error code&gt;</b>	Receiving MMS Message failed. Please refer to Chapter 4 for <error code>.
<b>+QMMNOTIFY: 3,&lt;mms index&gt;,0</b>	A new MMS Message has arrived. <b>AT+QMMRECV</b> can be used to receive it.
<b>+QMMNOTIFY: 4,0,&lt;error code&gt;</b>	Received a Service Indication (SI) message. For example, when a new MMS Message has arrived, but it has not been received via the command <b>AT+QMMRECV</b> , MMSC will send an SI message to inform you. Of course, other service applications also send SI messages, such as push email, stock information, news, or some advertising, etc. You can ignore this message.

## 4. Summary of error codes

Final result code **+CME ERROR: <err>** indicates an error related to mobile equipment or network. The operation is similar to **ERROR** result code. None of the following commands in the same command line is executed. Neither **ERROR** nor **OK** result code shall be returned. The listed **<err>** codes here are just related with MMS. About other **<err>** codes, please refer to document [1].

Code of <err>	Meaning
3901	Timeout
3902	URL too long
3903	Invalid URL
3904	Unsupported proxy
3905	Invalid proxy address
3906	IP address error
3907	DNS error
3908	Parameter error
3909	TO addresses exceeded
3910	CC addresses exceeded
3911	BCC addresses exceeded
3912	Appended file capacity exceeded
3913	File name too long
3914	The number of files exceeded
3915	Non-existent address
3916	UFS storage full
3917	Drive full
3918	Drive error
3919	File not found
3920	Invalid file name
3921	File already existed
3922	Failed to create file
3923	Failed to write file
3924	Failed to open file
3925	Failed to read file
3926	MMS busy
3927	Sending MMS busy
3928	Sending MMS stopped
3929	Already stopped to send
3930	Receiving MMS busy
3931	Receiving MMS stopped
3932	Already stopped to receive

3933	HTTP response failure
3934	Invalid MMS response
3935	MMS response error
3936	Invalid push message
3937	Already downloaded
3938	Network busy
3939	Failed to open network
3940	Network no configured
3941	Network deactivated
3942	Network error
3943	Network shutdown
3944	UART busy
3945	UART escaped
3946	Failed to create socket
3947	Failed to connect socket
3948	Failed to read socket
3949	Failed to write socket
3950	Socket closed
3951	MMS length error
3952	Failed to encode MMS
3953	Failed to decode MMS
3954	Failed to decode HTTP
3955	Failed to decode push message
3956	PDU(HEX) align error
3957	PDU(HEX) character error
3958	String too long
3959	MMS full
3960	Non-existent MMS
3961	Invalid address
3962	Voice call busy
3963	ALLOC memory failed

## 5. Reliable transmission

For reliable transmission when using "AT+QMMRR=6, ..." command to download the content of a file, it's recommended that users turn on hardware flow control capabilities, while also opening MCU hardware flow control function. Using the AT+IFC=2,2<CRLF> command to open the hardware flow control function. It is turned on by default.

As general serial transmission is reliable, in order to further reliability, we provide additional ways to verify the data transmission reliability by the command's response information.

When using " AT+QMMRR=6, ..." command to download a file, the module will report "+QMMRR: 6,<download size>,<checksum>" information tips at the end of data transmission. Then MCU can judge whether the data has lost by comparing the value of < download size> and <checksum>.

<download size> is the data length which the module received. MCU compares <download size> with the actual length of the file which MCU has received. If unequal, it means the module lost data.

<checksum> is calculated by doing XOR for every 2 bytes. Similarly MCU calculates the actual file's checksum as below example, and then compares this value with <checksum> which module reports. If not equal, the received data may be problematic. User can re-download data.

### Example for calculating checksum:

If the data length of the downloaded file is 9, the 16 hex values are as follows:

0x23 0x13 0x65 0x B6 0x76 0x88 0xA3 0xEF 0x55

So, checksum is calculated as follows:

checksum = 0x2313 XOR 0x65B6 XOR 0x7688 XOR 0xA3EF XOR 0x5500

Every two data form a group and do XOR with another group. If the last group is less than 2 bytes, supplement it with 0x00.

## 6. Examples

### 6.1. Set the parameters

```
AT+QIFGCNT=0
OK

AT+QICSGP=1,"CMWAP" // Set APN
OK

AT+QMMURL="http://mmsc.monternet.com" // Set the MMSC URL
OK

AT+QMMPROXY=1,"10.0.0.172",80 // Use HTTP protocol to send MMS
// Message, set the IP address and port of
// MMS proxy to "10.0.0.172" and 80.
OK
```

### 6.2. File transmit operation

Please refer to the document: [4] GSM\_FILE\_ATC

```
AT+QFUPL="test.txt",3222 // Upload the text file "test.txt"
CONNECT
<input file bin data>
+QFUPL: 3222,B3E4

OK

AT+QFDWL="test.txt" // Download the file "test.txt"
CONNECT
<output file bin data>
+QFDWL: 3222,B3E4

OK

AT+QFUPL="test2.txt",4222 // Upload the text file "test2.txt"
CONNECT
<input file bin data>
+QFUPL: 4222,13E4

OK
```





```

OK

AT+QMMSSEND=1 // Send the MMS Message
OK

+QMMNOTIFY: 1,0,0 // Send the MMS Message successfully

AT+QIDEACT //Deactivate GPRS context
DEACT OK

```

#### 6.4. Receive MMS Message

```

+QMMNOTIFY:3,1 // Receive an MMS push message,
                // indicating a new MMS, index is 1.

AT+QMMRECV=1,1 // Receive MMS Message from MMSC
OK

+QMMNOTIFY: 2,1,0 // Receive MMS Message successfully

AT+QIDEACT // Deactivate GPRS context
DEACT OK

```

#### 6.5. Manage received MMS Message

```

AT+QMMRM=1 // List MMS Message
+QMMRM: 1,"+8613950062882",1,"7/23/2009","0:39:4",3745

OK

AT+QMMRR=1,1 // Read MMS Message "Original address"
+QMMRR: 1,"+8613950062882"

OK

AT+QMMRR=4,1,1 // Read MMS Message title
+QMMRR: 4,"UTF8","abcde"

OK

AT+QMMRR=5,1 // List the files in the MMS Message
+QMMRR: 5,1,"test.txt","UTF8",3222 // It includes one file whose index is 1

```

**OK**

**AT+QMMRR=6,1,1**

// Get the data of the file **1** (defined by the second “**1**”) in the MMS **1** (defined by the first “**1**”)

**CONNECT**

<output file bin data>

**+QMMRR: 6,3222,B3E4**

**OK**

# QUECTEL



**Shanghai Quectel Wireless Solutions Co., Ltd.**

Room 501, Building 13, No.99, Tianzhou Road, Shanghai, China 200233

Tel: +86 21 5108 6236

Mail: [info@quectel.com](mailto:info@quectel.com)